

1. 2.4G Wireless Mode

2.4G mode supports windows, Mac OS, Linux, Unix, Android and other systems through dongle.

Step 1: Scan **2.4G wireless Mode** barcode. Scanner will pair with previous dongle by default.



2.4G Wireless Mode

Step 2: Scan **Quick Pair** barcode. The indicator light will flicker.



Quick Pair

Step 3: Plug in the dongle with the host device (within 60 seconds). If pair successfully, you will hear a beep and the indicator light is always on.

2. Common settings

System settings



Restore factory settings



Version Number

Batch/Storage Mode



Real time mode (Default)



Storage Mode



Transmit All Stored Barcodes



Total Stored Amount



Clean Stored Barcodes


Terminator Suffix



<Data><CR>(Default)



<Data><TAB>



No terminator suffix

Vibration (optional)



Vibration on (Default)



Vibration off

Scanner Power Time-out Timer



Time-out immediately



Time-out after 1min



Time-out after 5min



Time-out after 30min



No Time-out

Country Keyboard Layout

Note Keyboard layouts vary from country to country. The default setting is U.S. keyboard.



United States(default)




German



France



Spain



Italy




Japan



International universal keyboard



Portugal



United Kingdom



Brazil(Portuguese)



Russia

✘ How to use the setting barcode: You only need to find the barcode with the required function in the setting barcode and scan it once. If the buzzer beeps, it indicates that the scanning is successful.

✘ For additional information on using the scanner, please contact the vendor for a complete user manual.